



# Harmful Algal Blooms

## Early Detection using Hyperspectral Imaging from a Lightweight UAV

### ONGOING PROJECT WITH SIMULTANEOUS AIRBORNE AND GROUND-TRUTH DATA CAPTURE

Human waste contains significant amounts of biologically available nitrogen and phosphorus, and sewage and seepage from septic systems can release significant amounts of nitrogen and phosphorus into the environment. Agricultural fertilizers typically contain mostly nitrogen, phosphorus, and potassium, and run-off from over-fertilized fields can also cause increases in available nitrogen and phosphorus.

Combined with Global Warming (warmer water temperatures), excess nitrogen and phosphorus in bodies of water can lead to Harmful Algal Blooms (HABs)—also known as cyanobacterial HABs (CyanoHABs), where the population of one or more species of toxic plankton experiences a population boom. For example, warming temperatures in Lake Erie have contributed to extensive blooms of the cyanobacteria *Microcystis aeruginosa* that last into the early winter months.<sup>1</sup> In the past several years, such blooms have been found more often and in more places across the United States.

According to the US Centers for Disease Control and Prevention, these blooms can harm people, animals, and the environment when they:<sup>2</sup>

- Produce toxins
- Become too dense
- Deplete the oxygen in the water
- Release harmful gases

Harmful algae and cyanobacteria are a One Health issue and can affect ecosystems in many ways.<sup>3</sup>



Figure 1. Coastal Ocean Vision's boat on Santuit Pond in Mashpee, MA

## ELEMENTS NECESSARY FOR LIFE

### CHONSP: Carbon Hydrogen Oxygen Nitrogen Sulphur Phosphorous

- **Carbon:** Combines with Oxygen and Hydrogen to create Carbohydrates (Sugars, Starches, Cellulose) and Hydrocarbons (Fats and Oils).
- **Hydrogen and Oxygen:** In Carbohydrates and Hydrocarbons as above, as well as in Dihydrogen Monoxide ( $H_2O$ ), essential to life.
- **Nitrogen:** Ammonia ( $NH_3$ ), Amino Acids, Protein. Abundant in the atmosphere as  $N_2$ , but often the limiting factor in growth of living things (Nitrate fertilizer).
- **Sulphur:** Essential to all life, but not generally a limiting reagent
- **Phosphorous:** Essential to all cells; part of the phospho-lipid bilayer that makes up cell membranes.

An excess of N and P in an ecosystem can lead to "blooms" of otherwise less abundant organisms.

# The Culprit

Cyanobacteria or Blue-Green Algae are not actually bacteria nor algae. All plants have chloroplasts, which seem to be descended from cyanobacteria, ancient organisms. The evolution of cyanobacteria changed Earth's early atmosphere from Reducing (no Oxygen) to Oxidizing. They may have been the first organisms that successfully performed photosynthesis. One species, *Prochlorococcus*, is the most plentiful species on Earth (in the ocean) and produces 20% of Earth's oxygen. However, several species (*Dolichospermum*, *Woronichia*, and *Microcystis*) produce toxins that can harm people and animals such as fish and birds.



Figure 2. Harmful algal blooms on the surface of the pond

## CONTRIBUTING TO THE SOLUTION

Cyanobacteria have different photosynthetic pigments than “normal” algae, and since different pigments can have different spectra and hyperspectral imaging (HSI) can distinguish different spectra in different pixels; potentially, HSI can be used to identify and quantify Harmful Algal Blooms. Prompt identification can improve efficacy of mitigation strategies. Headwall is working with experts to get “ground truth” to test this detection method.

## BACKGROUND & TECHNOLOGY

Santuit Pond is a location in Mashpee, Massachusetts that has been impacted by HABs for many years.<sup>4</sup> Water quality is being monitored by several state, tribal, and local government agencies, academia, as well as by companies such as Coastal Ocean Vision and Headwall. Coastal Ocean Vision also maintains a number of HABStat sensors at fixed locations in the pond.

Headwall's technique of capturing full spectral data (hundreds of wavelengths) at each pixel from a

lightweight UAV (unmanned aerial vehicle) is well documented.<sup>5</sup> Combined with precise GPS coordinates and timestamps and available LiDAR (Light Detection And Ranging), a hyperspectral dataset was captured by a Headwall Nano-Hyperspec<sup>®</sup> VNIR sensor payload along with very precise elevation information below the flight path of the DJI Matrice 300 UAV over Santuit Pond in Mashpee, Massachusetts.

Simultaneous with the UAV flight Headwall partner Coastal Ocean Visions operated a proprietary HABStat Raman Imaging Flow Cytometer in the water from a small boat. The HABStat system uses high-speed Raman Spectroscopy and strobed imaging to acquire Raman spectra and cell images simultaneously. The Raman spectra represent a molecular fingerprint of a cell along with quantification of pigmentation such as chlorophyll and *phycocyanin*, as well as toxin if present. Deep Learning AI combines the spectral and imaging data to classify cells to species in real time.



Figure 3. Coastal Ocean Vision researchers studying Santuit Pond

## THE MISSION

A remote-sensing mission was undertaken by Headwall and Coastal Ocean Vision for June, August, and November of 2022. The Headwall team flew its off-the-shelf ‘turnkey’ Nano-Hyperspec<sup>®</sup> VNIR sensor with LiDAR on a DJI Matrice 300 UAV. The payload package weighs less than 4 lbs, keeping total take-off weight well below the FAA's Part 107 Small Unmanned Aircraft Rule. The Coastal Ocean Vision team operated a powered watercraft with a HABStat deployed in the water beside the hull.

The drone flew a pre-programmed ‘lawnmower’ pattern over the same area of Santuit Pond upon which the boat navigated. The teams spent a few hours on June 21,

# HARMFUL ALGAL BLOOMS

## Early Detection using Hyperspectral Imaging from a Lightweight UAV



Figure 4. Customer Success Engineer and FAA-Certified Drone Pilot Charles Kepler flying the drone holding the Nano-Hyperspec VNIR sensor

August 15 and November 11, 2022 capturing data and documenting the mission. In November the Mashpee Department of Natural Resources Harbormaster staff graciously assisted with a marine patrol boat and captain when the original boat was temporarily unavailable. All other aspects of the mission went smoothly.

### SIMULTANEOUS DATA CAPTURE

The benefit of flying the drone while the boat navigated the pond was obtaining so-called 'ground truth' data. Ground truth is information that is known to be true. Measurements from the flow-cytometry system in the water were compared with the simultaneous remote measurements from the drone via HSI. Since both systems utilized very precisely timed GPS systems, instances when the drone was directly over the boat were noted and confirmed looking at the 3D LiDAR point cloud and the spectra of the boat itself!

### RESULTS

CyanoHABS were at a low level in June when we conducted our first mission but started increasing rapidly in early July and reached intensive bloom conditions by mid-August during our second mission. The water was pea-soup green with a Sechi disk reading of < 5cm. Suddenly on August 28 the bloom crashed over an 8-hour period. This phenomena was noted by HABStats on the dock. Large 2-mm Chytrids were attaching to the Dolichospermum strands possibly causing them to sink out of the water column.

As shown here (Fig. 5) each LiDAR point has a location and a timestamp. Coloring the point cloud by time allows determination of exact Latitude, Longitude and Time of each boat image in the Hyperspectral data. This allowed




Figure 5. Boat Locations in LiDAR Time Data

precise correlation between local Hyperspectral classification and measurements from HABStats.




Figure 6. Part of Santuit Pond Study Area

Figure 6 is an RGB (conventional color) image from a Reflectance Image overlaid on Google Maps. Note the lighter and darker areas in the image. These are due to intermittent clouds changing the downwelling illumination. These intensity variations will affect the classification analysis.

Here you see a Full-Spectrum Reflectance orthomosaic classified with three HAB classes and two tree classes, generated from the data (Fig. 7). HAB classes are based on variations in apparent density of HAB in the RGB images.

Illumination Variations due to clouds produce classification artifacts along flight lines.




Figure 7. Initial Classification from August 15, 2022

## APPLICATION NOTE

## HARMFUL ALGAL BLOOMS Early Detection using Hyperspectral Imaging from a Lightweight UAV

Note the Reference Spectra shown (Fig. 7) and the June RGB and False-Color Classified orthomosaic images (Fig. 8). The green vascular plant *Elodea* choked the surface of the pond in many locations. It was so thick that it stalled the boat engine many times. Low levels of cyanoHABs fringed the pond around the coastline that was dominated by *Woronichia* and classified as HAB2.




Figure 8. Reference Spectra Expanded




Figure 9. Santuit Pond, June Classification

In contrast, the August Classification image (Fig. 10) shows greatly increased presence of HABs. The November classification images show very little indication of cyanoHABs in the center of the pond but two HAB groups are seen scattered along the coastline on both east and west coasts. HABStats on the dock showed moderate levels of *Aphanizomenon* and *Microcystis* which was classified as HAB1 and HAB2.




Figure 10. Santuit Pond, August Classification

As of the writing of this application note, presentations have been made at the AGU Annual Meeting in Chicago in December 2022<sup>6</sup> and an NAHEP Training-Workshop on Airborne Hyperspectral Remote Sensing for Agriculture in New Delhi in January 2023<sup>7</sup>. Headwall and Coastal Ocean Vision will continue this project in 2023.

<sup>1</sup>Record-setting algal bloom in Lake Erie caused by agricultural and meteorological trends consistent with expected future conditions, A.M. Michalak, et al., PNAS, v110, No. 16, <https://doi.org/10.1073/pnas.1216006110>

<sup>2</sup> <https://www.cdc.gov/habs/environment.html>, Harmful Algal Bloom (HAB)-Associated Illness webpage

<sup>3</sup> <https://www.cdc.gov/onehealth/index.html>, One Health is a collaborative, multisectoral, and transdisciplinary approach—working at the local, regional, national, and global levels—with the goal of achieving optimal health outcomes recognizing the interconnection between people, animals, plants, and their shared environment.

<sup>4</sup> <https://www.mashpeema.gov/natural-resources/watershed-based-solutions-increase-resilience-harmful-algal-blooms-santuit-pond-0>

<sup>5</sup> Hyperspec 101: Introduction to Hyperspectral Imaging video, <https://www.headwallphotonics.com/knowledge-center/video/mp4/hyperspectral-intro>; Application Note: Hyperspectral Imaging Explained, <https://www.headwallphotonics.com/knowledge-center/tech/pdf/hyperspectral-imaging-explained>

<sup>6</sup> INV23A-06 - Community and Commercial Monitoring of Cyanobacterial Blooms in Drinking and Recreational Bodies of Water by Air and on the Surface, C. Roberts, Headwall Photonics; S. Gallager, Coastal Ocean Vision, <https://agu.confex.com/agu/fm22/meetingapp.cgi/Paper/1206851>

<sup>7</sup> Airborne Imaging spectroscopy Beyond the Crop Field: Dr Carson Roberts, Ph.D., Headwall Photonics; National Agricultural Higher Education Project (NAHEP) sponsored Training/Workshop on Airborne Hyperspectral Remote Sensing for Agriculture hosted by the Centre for Advanced Agricultural Science and Technology (CAAST), Division of Agricultural Physics ICAR-Indian Agricultural Research Institute, New Delhi, <https://www.headwallphotonics.com/blog/nahep-2023>

[headwallphotonics.com](https://www.headwallphotonics.com)

Tel: +1 978-353-4100

Fax: +1 978-348-1864

Headwall Photonics Inc.

580 Main Street, Bolton, MA 01740 USA

[information@headwallphotonics.com](mailto:information@headwallphotonics.com)

